

**soudtec**  
BY PORODO



## **TRUE-WIRELESS BUDS**

SUPER BASS WITH ANC MODE

# PD-STWLEP015 OPERATION MANUAL

## User Manual

- **Brief Introduction**


**Item:** True Wireless Earphone PD-STWLEP015


**Model No.:** PD-STWLEP015

It is a true wireless blue-tooth earphone, each ear piece comes with a microphone that can be used individually or used together for stereo sound. The earphone supports music and calling functions.

- **Charge your True Wireless Earphone PD-STWLEP015**

Prior to use, charge your Wireless Earphones. Use the supplied Micro USB charging cable. Plug the cable into the TYPE C port which is located on the back of the charging case.





### ● Connecting/Bluetooth Pairing

1. Make sure the True Wireless Earphones are within 10 meters of the device you will be connecting to.
2. Remove both earphones from the charging case and place into your ears.
3. Turn on your device's Bluetooth. Most devices will automatically detect your earphones. Locate and select "Por-EP015". It will indicate that your earphones are now connected.

If your device does not automatically detect your earphones, make sure Bluetooth is turned on, do a **SEARCH** for "Por-EP015" and then click **CONNECT**.

## TWS (Por-EP015) Operation Instructions

No.	Item	Left earphone	Right earphone	Tone (Left)	Tone (Right)	LED Indication	Remark
1	Pairing Name	Por-EP015		/		/	
2	Power On	Open the earphone cover , automatically power on		Power on		The white light of the case is on for 1 second	
3	Power Off	Put it in the charging box, automatically power off		Power off		When any earphone is putted into the box, the white light of the case flashes once	
		Without connection , 10 minutes shutdown		Power off		White light of the case blinks three times quickly and then turns off	
4	TWS Pairing	No matter which earphone turns on first, two earphones automatically formed		/		TWS pairing status: White lights of the earphones keep flashing (0.2S)	
5	Connected with Phone	When the earphone is powered on, it enters the pairing + callback mode and shuts down without connection for 10 minutes		Connected		Pairing: White lights keep flashing (0.5S) Connected: Lights turn off	
6	Volume Control	No such function		/		/	

7	Pause/Play	Click once		/	/	
8	Media Selection	Double click on the left side--Previous Song	Double click on the right side--Next Song	/	/	
9	Mode Switch	Hold for 2 seconds to switch modes Prerequisites: The noise reduction mode is automatically switched when both earphones are formed, and the common mode is automatically switched when just single earphone is on		Normal mode - Transparent mode - Noise reduction mode (loop play)	/	
10	Call In	NA		The earphone ring tone is synchronized with the mobile phone ring tone		
11	Answer Calls	Double click when calling in		"DU"	/	
12	Ring Off	Double click during the call		"DU"	/	
13	Call Rejection	Press and hold for 2 seconds when calling in		"DU"	/	
14	SIRI ON	Triple-click		"DU"	/	

15	SIRI OFF	Operation: Click Prerequisites: SIRI is enabled. Click to exit SIRI, not pause playback	/	/	
16	Factory Data Reset	Put the earphones into the charging case. In the charging state, long press the button of the charging case for 3 seconds to force the progress pairing state of the earphones. Continue to long press for 10 seconds to restore the factory Settings PS: Full clear (both TWS pairing information and phone pairing information are cleared)	/		If the light of the charging case blinks three times slowly, the factory Settings are restored, the white lights of two earphones blink quickly for 0.2 seconds at the same time. The earphones will be successfully formed, and the white lights on both earphones blink quickly for 0.5 seconds
17	Loss of connection with mobile phone over distance/Bluetooth off/Active disconnection	The Earphone enters the connection back + pairing mode and shuts down without connection for 10 minutes	Disconnect-- Pairing		Pairing: Two white lights keep flashing (0.5S)
18	Low Battery Alarm	10% low power reminder, remind once every 3 minutes, about 3-4 times, low power reminder to shutdown time is about 10 minutes	Low Battery		Low Battery: The earphones white lights blink once every two seconds Battery lower side power off earlier
19	Earphone Charging	The charging case charges the earphones			Charging: The earphone lights are off Fully charged: The earphone lights are off
20	Earphone Case Charging	Plug it in--Start charging--Fully charged			Charging: Breathing White Fully charged: White light goes out White light of the Charging Case

## Specification and Features sheet

No.	Pairing Name	Por-EP015		
1	Single-earphone battery voltage	3.7	V	Single Earphone
2	Single-earphone battery capacity	55	mAh	
3	Wattage of a single-earphone battery	0.111	Wh	
4	Charging case battery voltage	3.7	V	Charging Case
5	Charging case battery capacity	500	mAh	
6	Wattage of charging case battery	1.850	Wh	
7	Charging voltage of charging case	5	V	

soundtec  
BY PORODO



سماعات لاسلكية حقيقية

صوت قوي مع وضع إلغاء الضوضاء النشط (ANC)



## ١٥-PD-STWLEP دليل التشغيل

كتيب المستخدم

مقدمة موجزة


المنتج: سماعة أذن لاسلكية حقيقية ١٥-PD-STWLEP



الموديل رقم: ١٥-PD-STWLEP

إنها سماعة أذن لاسلكية بلوتوث حقيقية، تأتي كل قطعة أذن مع ميكروفون يمكن استخدامها بشكل فردي أو استخدامها معًا للحصول على صوت ستيريو. تدعم السماعة وظائف الموسيقى والمكالمات.

☒ **شحن سماعة الأذن اللاسلكية الحقيقية ١٥-PD-STWLEP**

قبل الاستخدام، قم بشحن سماعات الأذن اللاسلكية الخاصة بك. استخدم كابل الشحن Micro USB المرفق. ادخل الكابل في منفذ TYPE C الذي يقع على الجزء الخلفي من علبة الشحن





## الاتصال / ربط البلوتوث

١. تأكد من أن سماعات الأذن اللاسلكية الحقيقية داخل نطاق ١٠ أمتار من الجهاز الذي ستقوم بالاتصال به.
٢. اخرج كلا السماعات من علبة الشحن وضعهما في أذنيك.
٣. قم بتشغيل بلوتوث جهازك. ستكتشف معظم الأجهزة سماعات الأذن تلقائيًا. ابحث عن "Por-EP٠١٥" واخترها. سيشير إلى أن سماعات الأذن الخاصة بك متصلة الآن. إذا لم تكتشف جهازك سماعات الأذن تلقائيًا، تأكد من تشغيل البلوتوث، ثم ابحث عن "Por-EP٠١٥" وانقر فوق الاتصال.

## تعليمات التشغيل لساعات الأذن اللاسلكية (TWS) بالرقم (Por-EP015)

.No	العنصر	سماعة جهة اليمين	سماعة جهة اليسار	نغمة جهة اليمين	نغمة جهة اليسار	مؤشر LED	ملاحظة
١	اسم الاقتران	Por-EP.١٥		/	/		
٢	تشغيل الطاقة	فتح غطاء السماعة، تعمل تلقائياً الطاقة		تشغيل		يُشعل الضوء الأبيض على العلبة لمدة ثانية واحدة.	
٣	إيقاف التشغيل الطاقة	وضعه في صندوق الشحن، يتم إيقاف تشغيله تلقائياً		إيقاف التشغيل		عند وضع أي سماعة في الصندوق، يومض الضوء الأبيض للعلبة مرة واحدة.	
		بدون اتصال، وفي غضون ١٠ دقائق سيتم إيقاف التشغيل		إيقاف التشغيل		يومض الضوء الأبيض للعلبة ثلاث مرات بسرعة ثم ينطفئ.	
٤	الاقتران للسماعات اللاسلكية الحقيقية	بغض النظر عن السماعة التي تُشغّل أولاً، تُشكّل السماعتان تلقائياً اقتراناً		/		حالة الاقتران للسماعات اللاسلكية الحقيقية: يومض الضوء الأبيض للسماعات بشكل مستمر (مرة كل ٢،٠ ثانية).	
٥	متصل بالهاتف	عند تشغيل السماعة، تدخل وضع الاقتران والاستدعاء وتُغلق بدون اتصال لمدة ١٠ دقائق		متصل		الاقتران: يومض الضوء الأبيض بشكل مستمر (مرة كل ٠,٥ ثانية). الاتصال: ينطفئ الضوء. (شريط إما عبارة عن فاصل أو تقسيم)	
٦	تحكم في مستوى الصوت	لا وجود لهذه الوظيفة.		/		/	

٧	وقفة/تشغيل	انقر مرة واحدة		/	/	
٨	اختيار الوسائط	انقر مرتين على الجانب الأيسر - الأغنية السابقة	انقر مرتين على الجانب الأيمن - الأغنية التالية	/	/	
٩	مفتاح الوضع	اضغط باستمرار لمدة ٢ ثانية للتبديل بين الأوضاع (السياقات) المطلوبة: يتم التبديل تلقائيًا إلى وضع تقليل الضوضاء عند تشكيل السماعتين، ويتم التبديل تلقائيًا إلى الوضع العادي عند تشغيل السماعة الأذن الفردية فقط.		الوضع العادي - الوضع الشفاف - وضع تقليل الضوضاء (تكرار التشغيل)	/	
١٠	استقبال المكالمات	NA		نغمة السماعة متزامنة مع نغمة الهاتف المحمول		
١١	الرد على المكالمات	انقر مرتين عند استقبال المكالمة.		"DU"	/	
١٢	أنهى محادثة هاتفية	انقر مرتين أثناء المكالمة.		"DU"	/	
١٣	رفض المكالمات	اضغط باستمرار لمدة ٢ ثانية عند استقبال المكالمة.		"DU"	/	
١٤	قم بتشغيل SIRT	انقر ثلاث مرات.			/	

١٥	إيقاف تشغيل SIRI	العملية: النقر. المتطلبات الأساسية: SIRI مُفعّل. انقر للخروج من وضع SIRI، وليس لإيقاف التشغيل المؤقت.	/	/	
١٦	إعادة ضبط البيانات المصنعية	ضع سماعات الأذن في علبة الشحن. في حالة الشحن، اضغط باستمرار على زر العلبة لمدة ٣ ثوانٍ للدخول إلى وضع إقران سماعات الأذن بالقوة. استمر في الضغط باستمرار لمدة ١٠ ثوانٍ لاستعادة الإعدادات المصنعية. ملاحظة: إعادة الضبط الكامل (يتم مسح معلومات الإقران بين سماعات الأذن ومعلومات الإقران بالهاتف).	/	إذا وامض ضوء علبة الشحن ثلاث مرات ببطء، فإن الإعدادات المصنعية قد تمت استعادتها، ويومض ضوء السماعتين الأبيض بسرعة لمدة ٠,٢ ثانية في نفس الوقت. ستتمكن السماعات من التشكيل بنجاح، ويومض ضوء السماعتين الأبيض بسرعة لمدة ٠,٥ ثانية.	
١٧	فقدان الاتصال مع الهاتف المحمول عند مسافة بعيدة/إيقاف البلوتوث/قطع الاتصال النشط	تدخل سماعة الأذن في وضع الاتصال والإقران وتُطفأ بدون اتصال لمدة ١٠ دقائق.	فصل الاتصال - الإقران	الاقتران: يومض ضوء السماعتين الأبيض بشكل مستمر (٠,٥ ثانية).	
١٨	تحذير من انخفاض البطارية	تذكير بانخفاض مستوى البطارية ١٠٪، يذكر مرة كل ٣ دقائق، حوالي ٣-٤ مرات، ومدة التذكير بانخفاض مستوى البطارية إلى وقت الإغلاق حوالي ١٠ دقائق.	انخفاض مستوى البطارية	انخفاض مستوى البطارية: يومض ضوء السماعتين الأبيض مرة كل ثانيتين.	البطارية تنخفض إلى أدنى مستوى يؤدي إلى إيقاف التشغيل مبكرًا
١٩	شحن سماعة الأذن	علبة الشحن تشحن سماعات الأذن.		الشحن: ينطفئ ضوء السماعة. الشحن بالكامل: ينطفئ ضوء السماعة.	
٢٠	شحن علبة سماعة الأذن	قم بتوصيلها - تبدأ عملية الشحن - تم الشحن بالكامل.		شحن: ضوء أبيض يتنفس. شحن بالكامل: ينطفئ ضوء السماعة الأبيض.	الضوء الأبيض لعلبة الشحن

No.	اسم الاقتران	Por-EPO15		
١	جهد بطارية السماعه الأذن الفردية	3.7	V	السماعة الواحدة
٢	سعة بطارية السماعه الأذن الفردية	55	mAh	
٣	القدرة الكهربائية لبطارية السماعه الأذن الفردية	0.111	Wh	
٤	جهد بطارية علبة الشحن	3.7	V	علبة الشحن
٥	سعة بطارية علبة الشحن	500	mAh	
٦	القدرة الكهربائية لبطارية علبة الشحن	1.850	Wh	
٧	جهد الشحن لعلبة الشحن	5	V	